



Model DA05 Model DA07 Model DA10



Metallic and Non-Metallic Surge Dampeners

Table of Contents

Principle of Operation	1
Temperature Limitations	1
Installation & Startup	1
Service & Warranty	1
Dimensions	2
Installation Guide	3
Repair Parts List	4
Repair Parts Drawing	5
CE Declaration of Conformity - Machinery	6



The Warren Rupp, Inc. Surge Dampener reduces flow and pressure pulsation which is characteristic of reciprocating pumps.

PRINCIPLE OF OPERATION

The surge dampener uses a flexible virgin PTFE diaphragm to separate a liquid chamber from a compressed air chamber. After the dampener is manually charged with air, the diaphragm strokes at the same rate as the pump strokes. This movement effectively "dampens" flow and pressure fluctuations.

TEMPERATURE LIMITATIONS

Operating temperature limitations are as follows.

Material	Minimum Temp.	Maximum Temp.
PVDF	0°F / -18°C	212°F / 100°C
Nylon	32°F / 0°C	180°F / 82°C
Polypropylene	32°F / 0°C	180°F / 82°C
Virgin PTFE	-35°F / -31°C	212°F / 100°C
Nitrile	-10°F / -23°C	190°F / 88°C

INSTALLATION & START-UP

Locate the unit in the discharge piping near the pump. The dampener will operate in any position. However, when used with liquids that tend to settle out, the unit should be installed at the top side of piping to provide easy discharge of foreign solids by gravity.

Adjust the inlet air pressure to the dampener until the pump runs as smoothly as possible. Watch the liquid discharging, or use a gauge, to detect pressure fluctuations. Then adjust pressure to the unit as needed.

NOTE: Self-relieving regulator 020-039-000 will make these adjustments easier.

SERVICE

When service is required on the dampener, remove the 8 capscrews. The wetted chamber can be removed from the unit and exposes the diaphragm. Remove the diaphragm. When reassembling the wetted chamber onto the air chamber, use a torque wrench set at 70 in/lbs. (7.9 Newton meters)

WARRANTY

This unit is guaranteed for a period of five years against defective material and workmanship.

IMPORTANT


Read these safety warnings and instructions in this manual completely, before installation and start-up of the surge dampener. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the surge dampener, and void factory warranty.

CAUTION


Maximum operating pressure is 100 psi (7 bar). Limitations are based upon mechanical stress only and may be significantly altered by pumping certain chemicals. Consult engineering guides for chemical compatibilities and temperature limits.

CAUTION


Before surge dampener operation, inspect all gasketed fasteners for looseness caused by gasket creep. Re-torque loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



DA05 Metallic and Non-Metallic



DA07




DA10

INSTALLATION GUIDE


Top Discharge Ball Unit

Available from
Warren Rupp, Inc.

- ① Surge Dampener
- ② Filter/Regulator
- ③ Lubricator
- ④ Air Dryer




CAUTION
The air exhaust should be piped to an area for safe disposition of the product being pumped, in the event of a diaphragm failure.



ITEM NO.	PART NUMBER	DESCRIPTION	TOTAL RQD.	Repair Parts shown in bold face (darker) type are more likely to need replacement after extended periods of normal use. They are readily available from most Warren Rupp, Inc. distributors. The pump owner may prefer to maintain a limited inventory of these parts in his own stock to reduce repair downtime to a minimum.
1	196-161-552	Chamber, Outer	1	
	196-161-520	Chamber, Outer	1	
	196-161-542	Chamber, Outer	1	
	196-171-110	Chamber, Outer (DA05 Metallic only)	1	
	196-171-157	Chamber, Outer (DA05 Metallic only)	1	
2	360-099-360	Gasket, Spacer	1	
3	334-103-552	Flange, Threaded 1/2" NPT (DA05)	2	
	334-103-542	Flange, Threaded 1/2" NPT (DA05)	2	
	334-103-600	Flange, Threaded 1/2" NPT (DA05)	2	
	334-109-110	Flange, Threaded 1/2" NPT (Metallic DA05 only)	2	
	334-109-150	Flange, Threaded 1/2" NPT (Metallic DA05 only)	2	
	334-104-552	Flange, Threaded 3/4" NPT (DA07)	2	
	334-104-542	Flange, Threaded 3/4" NPT (DA07)	2	
	334-104-600	Flange, Threaded 3/4" NPT (DA07)	2	
	334-107-552	Flange, 1" ANSI (DA10)	2	
4	135-022-115	Bushing, Reducer	2	
5	196-166-552	Chamber, Inner	1	
6	720-058-600	Seal, Flange	2	
	720-063-600	Seal, Flange (Metallic DA05 only)	2	
7	286-097-600	Diaphragm	1	
8	171-064-115	Capscrew Hex Flange 5/16 -18 x 1.50	4	
	171-064-308	Capscrew Hex Flange 5/16 -18 x 1.50	4	
	170-029-330	Capscrew, Hex Flange x 1.25 (Metallic DA05 only)	4	
9	544-005-115	Nut 5/16 Hex Flange Nut 5/16-18	10	
	544-005-308	Nut 5/16 Hex Flange Nut 5/16-18	10	
	545.004-330	Hex Flange Nut (Metallic DA05 only)	10	
10	171-070-115	Capscrew Hex Flange 5/16 -18 x 3.00	6	
	171-070-308	Capscrew Hex Flange 5/16 -18 x 3.00	6	
	171-070-330	Capscrew, Hex Flange (Metallic DA05 only)	2	
11	171-069-115	Capscrew Hex Flange 5/16 -18 x 2.5	2	
	171-069-308	Capscrew Hex Flange 5/16 -18 x 2.5	2	
	171-069-330	Capscrew, Hex Flange (Metallic DA05 only)	2	
12	538-002-115	Nipple 1/8 NPT	1	
13	020-039-000	Regulator W/Gauge	1	
14	171-063-115	Capscrew Hex Flange 5/16 -18 x 1.50	4	
	171-063-308	Capscrew Hex Flange 5/16 -18 x 1.50	4	
	170-045-330	Capscrew Hex Flange 5/16 -18 x 1.25	4	
15	900-004-330	LockWasher (DA05 Metallic Only)	14	
16	901-038-115	Flat Washer (Non-Metallic Only)	2	

REPAIR PARTS DRAWING





Declaration of Conformity

Manufacturer:

**Warren Rupp, Inc.®, 800 N. Main Street, P.O. Box 1568,
Mansfield, Ohio, 44901-1568 USA**

certifies that Air-Operated Double Diaphragm Pump Series: HDB, HDF, M Non-Metallic, S Non-Metallic, M Metallic, S Metallic, T Series, G Series, RS Series U Series, EH and SH High Pressure, W Series, SMA and SPA Submersibles, and Tranquilizer Surge Suppressors comply with the European Community Directive 2006/42/EC on Machinery, according to Annex VIII. This product has used Harmonized Standard EN 809, Pumps and Pump Units for Liquids - Common Safety Requirements, to verify conformance.

David Roseberry

Signature of authorized person

David Roseberry

Printed name of authorized person

Revision Level: E

October 20, 2005

Date of issue

Engineering Manager

Title

MAY 27, 2010

Date of revision

